

## RELEASE NOTES

VibroSight® software  
version 2.11.5



**Meggitt SA**  
Route de Moncor 4  
PO Box 1616  
CH - 1701 Fribourg  
Switzerland

## REVISION RECORD SHEET

SW version / RN edition	Date of issue	Written and modified by	Description	Signature
2.11.5 / 1	04 July 2014	P. Ward	This document corresponds to VibroSight version 2.11.5.	PW

	Department	Name	Date	Signature
Technical content approved by	Project Management	J. Theraulaz	04 July 2014	JT
	Product Management	A. Fernandez	04 July 2014	AF
Document released by	Technical Publications	P. Ward	04 July 2014	PW

*The duly signed master copy of this page is stored by the Technical Publications Department of Meggitt SA and can be obtained by writing to the Technical Publications Manager.*

## **IMPORTANT NOTICE**

All statements, technical information and recommendations in this document which relate to the products supplied by Meggitt Sensing Systems are based on information believed to be reliable, but unless otherwise expressly agreed in writing with Meggitt SA, the accuracy or completeness of such data is not guaranteed. Before using this product, you must evaluate it and determine if it is suitable for your intended application. Unless otherwise expressly agreed in writing with Meggitt SA, you assume all risks and liability associated with such use. Meggitt Sensing Systems takes no responsibility for any statements related to the product which are not contained in a current English language Meggitt Sensing Systems publication, nor for any statements contained in extracts, summaries, translations or any other documents not authored and produced by Meggitt Sensing Systems.

## **EXPORT CONTROL**

The information contained in this document may be subject to export control regulations of the European Community, USA or other countries. Each recipient of this document is responsible for ensuring that the transfer or use of any information contained in this document complies with all relevant export control regulations. ECN N/A.

## **COPYRIGHT**

Copyright © Meggitt SA, 2014

All rights reserved

Published and printed by Meggitt SA in Fribourg, Switzerland

The names of actual companies and products mentioned herein may be the trademarks of their respective owners.

The information contained in this document is subject to change without notice. This information shall not be used, duplicated or disclosed, in whole or in part, without the express written permission of Meggitt Sensing Systems.

---

## PREFACE

### About these release notes

This document provides important information about the VibroSight® software from Meggitt Sensing Systems. It is applicable to all VibroSight-based condition monitoring and machinery protection systems using the versions of software described by this document, namely:

- VibroSight software version 2.11.5 (CD part number 609-004-000-025).

This document contains information about changes to the software since the previously released version (VibroSight 2.11.4), such as new features and improvements, solved problems and bug fixes, and hardware and software compatibility.

For more general information on the actual software, or the entire condition monitoring system (CMS), refer to the following Meggitt Sensing Systems (MSS) documentation:



*VibroSight software data sheet*  
(MSS document ref. 660-020-005-214A)



*Getting started with VibroSight installation guide*  
(MSS document ref. 660-010-006-216A)



*VibroSight help*



*XMV16 / XIO16T extended vibration monitoring card pair data sheet*  
(MSS document ref. 660-020-010-208A)










*VibroSight application notes and technical notes.*

Users who are familiar with VibroSight may also find it useful to refer to the release notes included in earlier versions of the software:

- VibroSight 2.9.0 (MSS document ref. VIBROSIGHT-RN/E)
- VibroSight 2.9.1 (MSS document ref. VIBROSIGHT-RN/E)
- VibroSight 2.9.2 (MSS document ref. VIBROSIGHT-RN/E)
- VibroSight 2.9.4 (MSS document ref. VIBROSIGHT-RN/E)
- VibroSight 2.9.5 (MSS document ref. VIBROSIGHT-RN/E)
- VibroSight 2.9.6 (MSS document ref. VIBROSIGHT-RN/E)
- VibroSight 2.9.7 (MSS document ref. VIBROSIGHT-RN/E)
- VibroSight 2.10.0 (MSS document ref. VIBROSIGHT-RN/E)
- VibroSight 2.10.1 (MSS document ref. 660-010-013-201A)
- VibroSight 2.11.0 (MSS document ref. 660-010-013-203A)
- VibroSight 2.11.1 (MSS document ref. 660-010-013-204A)
- VibroSight 2.11.2 (MSS document ref. 660-010-013-205A)

- VibroSight 2.11.3 (MSS document ref. 660-010-013-206A)
- VibroSight 2.11.4 (MSS document ref. 660-010-013-207A).

## Structure of the release notes

This document presents information in the following order: general items first, then in terms of the software modules that constitute VibroSight, such as  Configurator,  Event Viewer,  Mimic,  Scope,  Server,  System Manager and  Vision.

You should read those sections that are most relevant to you and then keep the document for future reference.

## Version identifiers

A complete VibroSight software product version number has four components x.x.x build x (or x.x.x.x) that provide the following information:

- Major release identifier: x.x.x build x (or x.x.x.x)
- Minor release identifier: x.x.x build x (or x.x.x.x)
- Update identifier: x.x.x build x (or x.x.x.x)
- Build identifier: x.x.x build x (or x.x.x.x)

The version identifiers for installed software appear in the Help About box (obtained using **Help > About ...** in any VibroSight software module).

## Terminology

To distinguish between the different Meggitt Sensing System products that can be used with the VibroSight software, the following terminology is used in this document:

- VM600 card – to refer to the VibroSight-software compatible cards that are installed in a VM600 rack. The currently available VM600 cards that are designed for operation with the VibroSight software are the XMx16 card pairs (XMC16 / XIO16T, XMV16 / XIO16T and XMVS16 / XIO16T) and the CPUR card (for configuration only).

Where XMx16 card is used in this document, it refers to XMC16 / XIO16T, XMV16 / XIO16T and XMVS16 / XIO16T cards, unless otherwise stated.

- VibroSmart DMS module or VibroSmart DMS device – to refer to VibroSight-software compatible modules or devices that are used in a distributed monitoring system. The currently available VibroSmart DMS modules and devices that are designed for operation with the VibroSight software are the VSI010, VSN010 and VSV300.

Where VibroSmart DMS module is used in this document, it refers to VSI010 and VSV300 modules, unless otherwise stated.

Where VibroSmart DMS device is used in this document, it refers to the VSN010 device, unless otherwise stated.

## TABLE OF CONTENTS

Revision record sheet.....	2
Important notice.....	3
Export control .....	3
Copyright .....	3
Preface .....	4
About these release notes.....	4
Structure of the release notes .....	5
Version identifiers .....	5
Terminology .....	5
Table of contents .....	7
1. Licensing .....	10
2. Features .....	10
General.....	10
2.1. VibroSight OPC Server improvements.....	10
2.2. Changing VibroSight Mimic and VibroSight Vision project data sources.....	12
2.3. Working with VibroSight Mimic and VibroSight Vision projects with no data sources .....	12
VibroSight Configurator .....	13
2.4. S <sub>max</sub> processing .....	13
VibroSight Mimic.....	13
2.5. Project framework.....	13
2.6. Importing Mimic documents .....	13
VibroSight System Manager.....	15
2.7. Default data directory .....	15
VibroSight Vision .....	15
2.8. Time Range tool window .....	15
2.9. Default plot settings .....	16
2.10. Default behaviour of Time Range tool window when working with Alarms.....	16
3. Solved problems and bug fixes .....	18
General.....	18
3.1. Improvements and bug fixes .....	18
3.2. Problems with VibroSight OPC .....	18
3.3. Problems with data quality indicators .....	18
VibroSight Configurator .....	18
3.4. VM600 XMx16 card qualifiers .....	18
VibroSight Event Viewer.....	19
VibroSight Mimic.....	19
VibroSight System Manager.....	19
VibroSight Vision .....	19

---

4. Known issues .....	20
4.1. Changing a VibroSight Server's maximum RAM cache size when DSNs are not used .....	20
4.2. Display of timestamps in VibroSight Vision .....	21
4.3. Small "holes" in plotted data for larger VibroSight Vision projects when viewing live data .....	21
4.4. Missing data for XMV16 and XMVS16 cards .....	21
4.5. VibroSight Server and Host Service restart required after changes to network adapter .....	22
4.6. Length limitation of VibroSight Server instance names .....	22
4.7. VibroSight client connections to local and remote VibroSight Servers are mutually exclusive..	22
4.8. VibroSight Servers listen to a single IP address .....	22
4.9. Gaps in logged Modbus data .....	22
4.10. Display of timestamps in VibroSight clients other than VibroSight Vision.....	23
4.11. Display of devices in VibroSight System Manager.....	23
4.12. VibroSight Mimic backwards compatibility .....	23
5. Compatibility .....	24
5.1. VibroSight software .....	24
5.1.1. Microsoft Windows operating systems .....	24
5.1.2. Microsoft .NET Framework.....	25
5.1.3. Sybase SQL Anywhere 11 software.....	25
5.1.4. VM600 CMS software.....	25
5.1.5. SIMATIC Step 7 software .....	26
5.1.6. Microsoft Visual C++ Redistributable Package .....	26
5.1.7. OPC Foundation OPC Core Components Redistributable .....	26
5.2. VM600 cards .....	27
5.2.1. Firmware.....	27
5.3. VibroSmart DMS devices .....	27
5.3.1. Firmware.....	27
6. Upgrade procedure.....	29
6.1. VibroSight software user settings.....	29
6.2. Upgrading the VibroSight software.....	30
6.2.1. Updating the internal structure of a VibroSight database.....	31
6.3. Upgrading the Sybase SQL Anywhere 11 software.....	32
6.4. Updating the VibroSight hardware .....	34
6.4.1. VM600 card firmware .....	34
6.4.2. VibroSmart DMS device firmware .....	37
6.4.3. Updating the firmware using VibroSight System Manager.....	41
6.5. Final checks.....	43
7. Customer support .....	44
7.1. Contacting us.....	44
7.2. Technical support .....	44
7.3. Sales and repairs support .....	44



- Appendix..... 45
  - VibroSight software and Windows operating system compatibility ..... 46
  - Microsoft .NET Framework versions pre-installed on Windows operating systems ..... 46
  - VibroSight software’s Microsoft .NET Framework requirements..... 46

## 1. Licensing

In general, the licence key required to enable purchased product options remains unchanged between update level releases. For example, from version 2.11.4 to version 2.11.5.

However, a new licence key is required for upgrades between major and minor version releases. For example, from version 2.10.x to version 2.11.x.

To obtain a new VibroSight licence key file or for further information on licence keys, contact Meggitt Sensing Systems customer support. See 7 Customer support.

## 2. Features

### General

#### 2.1. VibroSight OPC Server improvements

Much more information (OPC Item Properties) is now available for each published measurement. Where applicable, the following properties are included: Engineering unit, Description, Full display range maximum, Full display range minimum, Time zone, Physical quantity, Qualifier, Unit and qualifier, Activation state, Machinery full path, Hardware full path, Data type, Device type, Sensitivity, Signal origin, Speed reference, Speed value, Severity level, Severity name, Sampling mode, Bandwidth, Resolution, Point count, Line count, Window, Band start and stop.

Previously, only the most important parameters for each measurement were available, such as Engineering unit, Physical quantity and Qualifier.

The way in which dynamic data types (**Waveforms**, **Spectra** and **Orbits**) are published via OPC has been changed, as follows:

- A waveform is published as an "Amplitude" array containing "Number of samples", "Tmax (s)" (duration of the whole waveform) and "Revmax (rev)" (number of revolutions in the whole waveform, if available). Note: There is no "Amplitude" node in the tree structure.

Previously, a waveform was published as an "Amplitude" array and a "Time" array.

- A spectra is published as an "Amplitude" array and a "Phase" array, if configured, containing "Number of lines", "Fmax (Hz)" (highest time frequency in the whole spectrum) and "Ordmax (Ord)" (highest spatial frequency in the whole spectrum, if available).

Previously, a spectra was published as an "Amplitude" array and a "Frequency" array.

- An orbit is published as an "X" array and a "Y" array containing "Number of samples", "Tmax (s)" (duration of the whole waveform), "Revmax (rev)" (number of revolutions in the whole waveform, if available).

Previously, an orbit was published as an "X" array, a "Y" array and a "Time" array.

To support VibroSight OPC Server improvements, there have been several improvements to the user interface used to create a VibroSight OPC Server configuration, including:

- The root node of the **Input server** is no longer included in the **Published measurements** tree structure (as it serves no purpose since only a single VibroSight Server can be used as the data source for a VibroSight OPC Server).
- Under **Settings**, the default phase qualifier box is now called **Default phase qualifier** (previously, it was **Phase qualifier**).
- Under **Settings**, the **Publish** controls can be used to selectively filter the measurement data in the VibroSight Server configuration to publish:
  - The first drop-down box is used to select either the enabled measurements only (**Only enabled**, the default) or all measurements that are available (**Enabled and disabled**).
  - The second drop-down box is used to select the type of measurement data to publish. Either all measurements (**Select All**) or any combination of data types (**Variables**, the default, **Waveforms**, **Spectra**, **Orbits**, **System data**) can be published.
  - The third drop-down box is used to select measurements from the Machinery view tree structure only (**From the machinery view only**), from the Hardware view tree structure only (**From the hardware view only**) or from both tree structures (**From the machinery and hardware views**, the default).

Previously, the VibroSight OPC Server published all of the measurement data (static and dynamic data types) that were available from the VibroSight Server.

- Under **Published measurements**, the **Customize hierarchy structure** button can be used to edit the published hierarchy structure that is used for the measurement data. For example, this allows:
  - The default root node names ("Machinery view" or "Hardware view") used in the exported OPC path to be customised by the user.
  - The structure of the default paths used for the Machinery view (**Machinery view components**) and Hardware view (**Hardware view components**) used in the exported OPC path to be customised by the user.

Measurement data (OPC items) with conflicting paths will not be published via OPC, but conflicts are detected and displayed to the user using message boxes.

---

**NOTE:** In VibroSight Configurator, the effects of the **Publish** and **Customize hierarchy structure** controls can immediately be seen in the **Published measurements** tree structure of the user interface.

---

---

## 2.2. Changing VibroSight Mimic and VibroSight Vision project data sources

The behaviour of VibroSight Mimic and VibroSight Vision has been improved in order to allow the data source for a project to be changed.

For example, this feature could be used to develop a VibroSight Mimic or VibroSight Vision project on one computer that uses a “test” database, then deploy the project on another computer that uses a “live” database.

To change the data source for an existing VibroSight Mimic or VibroSight Vision project:

1. Start VibroSight Mimic or VibroSight Vision as required.
2. Open an existing project.
3. Click **File > Link To New Data Source** and use the Data Sources Selection dialog box that appears to navigate and select a data source (VibroSight Servers or VibroSmart DMS modules) on the network, then click **Finish**.
4. The VibroSight Mimic or VibroSight Vision project updates its project file and starts using the new data source.

---

**NOTE:** The properties of the objects in the VibroSight Mimic or VibroSight Vision project will be kept where possible. However, if the new data source does not use the same configuration names and structure, then some properties will be lost.

(In general, if a Machinery view path is available for a data entity then the matching will be done based on the Machinery view path, otherwise the Hardware view path will be used.)

For VibroSight Mimic and VibroSight Vision, if there is no corresponding configuration object, the Vision object will be removed.

For VibroSight Mimic, if there is no corresponding configuration object, the Mimic object will be kept but without the Associated data.

---

Previously, when a new VibroSight Mimic or VibroSight Vision project was created, the Data Sources Selection dialog box was used to select the data source to be used for the project and it was not possible to subsequently change it.

See also 2.3 Working with VibroSight Mimic and VibroSight Vision projects with no data sources.

## 2.3. Working with VibroSight Mimic and VibroSight Vision projects with no data sources

The behaviour of VibroSight Mimic and VibroSight Vision has been improved in order to allow a project to be opened and worked with even when the data source is unavailable.

Previously, it was not possible to open a VibroSight Mimic or VibroSight Vision project if the data source was unavailable.

See also 2.2 Changing VibroSight Mimic and VibroSight Vision project data sources.

## VibroSight Configurator

### 2.4. $S_{max}$ processing

A **Qualifier** (rectifier) field has been added to the  $S_{max}$  processing function so that the  $S_{max}$  output can be made available as either a peak-peak value or a peak value. Previously,  $S_{max}$  was available as a peak-peak value only.

The new qualifier is available in the  $S_{max}$  data entity parameters window (available under a Dual Shaft Relative Processing Block).

## VibroSight Mimic

### 2.5. Project framework

The project framework implemented by VibroSight Mimic has been improved to include version information (as per VibroSight Vision) in order to improve the compatibility between projects created with different versions of VibroSight Mimic.

This means that starting with VibroSight 2.11.5, Mimic projects will be more compatible with future versions of VibroSight, thereby eliminating the requirement for the recreation of Mimics. However, since VibroSight 2.11.5 is the first version of VibroSight Vision to include the improved project framework, the benefits of these improvements will only be seen with VibroSight 2.11.6 or later.

For example, when future versions of VibroSight Mimic open a project created with VibroSight 2.11.5, VibroSight Mimic will be able to:

- Know of any changes in the VibroSight Mimic software that will affect project compatibility.
- Inform the user if the project needs to be updated.
- Update the project as required.
- Optionally, back up the project as required.

---

**NOTE:** VibroSight 2.11.5 is also able to open and work with Mimic projects created with VibroSight 2.11.0 or later, if the corresponding database had been updated as required.

---

See also 4.12 VibroSight Mimic backwards compatibility.

### 2.6. Importing Mimic documents

VibroSight Mimic has been improved in order to allow Mimic documents from one Mimic project to be included in another Mimic project.

This new feature can be used to save time when developing Mimic projects as existing Mimic documents can be easily and quickly imported into a Mimic project, whereas previously, Mimic

documents always had to be created in a Mimic project (even if a suitable or similar Mimic document already existed).

To import an existing Mimic document into a Mimic project:

1. Start VibroSight Mimic.
2. Open an existing or create a new project.
3. Click **Edit Mode** on the toolbar.
4. Click **File > Import** and use the Open dialog box that appears to navigate the folders on the computer and select an existing Mimic project (\*.vsmimic), then click **Open**.
5. Use the Import Mimic Pages dialog box that appears to select the Mimic document or documents to import from the existing Mimic project.  
Select or clear the individual check boxes corresponding to the Mimic document or documents to import. The check box corresponding to Page Name (top) can also be used to select or clear all Mimic documents as required. Then click **OK**.
6. The selected Mimic document or documents are imported into the Mimic project using their original names and can be edited as required.

---

**NOTE:** The properties of the Mimic objects in an imported Mimic document will be kept where possible.

However, if the VibroSight Server associated with the Mimic project does not use the same configuration names and structure, then some properties will be lost. Typically, this includes the Associated data (under General) and the Target (under Link).

---

## VibroSight System Manager

### 2.7. Default data directory

When the VibroSight software is installed, default folders are used for the program files (VibroSight software) and data files (configuration and measurement data), as follows:

- C:\Program Files (x86)\Meggitt\VibroSight 2 – on 64-bit versions of Windows
- C:\Program Files\Meggitt\VibroSight 2 – on 32-bit versions of Windows
- C:\VibroSight Data

---

**NOTE:** The default program and data folders can be changed during the VibroSight software installation process, by selecting **Custom** for the Setup Type (rather than **Typical**) and then specifying different program and data folders.

---

Previously, it was only possible to change the default VibroSight folders after installation by editing the Windows registry.

It is now possible to change the default VibroSight data folder after installation using a VibroSight System Manager command: **Change default data directory**, under **VibroSight Computer**.

## VibroSight Vision

### 2.8. Time Range tool window

The Time Range tool window has been improved to include a progress indicator and a cancel button when working in Machine states mode or Alarms mode with large databases.

When the Time Range tool window is being used in the Machine states or Alarms modes of operation and large quantities of measurement data are being retrieved from a VibroSight Server database:

- A **Loading data** progress indicator is now displayed in the status bar of the VibroSight Vision project user interface.
- A **Cancel** button is now also displayed in the Time Range tool window in order to allow the communications between VibroSight Vision and the VibroSight Server database to be interrupted.

Previously, there was no progress indicator or cancel button and the user had to wait until the current application of the Time Range tool window settings was completed before continuing.

## 2.9. Default plot settings

Each type of VibroSight Vision plot has default plot settings that can be changed to meet the requirements of the user.

The **Tools > Options** command is used to display the Options dialog box, where the default settings for each type of VibroSight Vision plot are displayed and can also be changed.

---

**NOTE:** In the **Options** dialog box, the default plot settings of a VibroSight Vision plot are organised and displayed as follows:

- Select **Default Plot Settings** (left pane) to display the default plot settings that are common to all plots (right pane).
- Select a specific plot type, such as Bar Chart Plot or Spectrogram plot (left pane) to display the default plot settings that are specific to an individual type of plot (right pane).

---

However, some users were unable to find the default settings that are common to all plots (**Default Plot Settings**). So, a link was added to the default plot settings specific to each individual type of plot (right pane) in order to prompt the user to access and use the common default plot settings.

Now, clicking on the new link (**Common Plot Settings**) in the right pane displays the default plot settings that are common to all plots (equivalent to clicking **Default Plot Settings** in the left pane.)

## 2.10. Default behaviour of Time Range tool window when working with Alarms

When using the alarms historical data mode of the VibroSight Vision Time Range tool window, the measurement data stored in the VibroSight Server database is accessed, retrieved and displayed in terms of the severity states (alarms) that the machinery being monitored has experienced. That is, the measurement data is displayed using time ranges that are defined by alarms.

However, it can also be of interest to view the time leading up to an alarm condition and the time following an alarm condition, in order to help identify the machinery conditions that caused the alarm. So a new option has been added in VibroSight Vision that allows a fixed period of time before an alarm and/or a fixed period of time after an alarm to be automatically included when working with the Time Range tool window in Alarms mode.

The **Tools > Options** command is used to display the Options dialog box, where the Time Range settings to be applied in Alarms mode are displayed and can also be changed.

---

**NOTE:** In the **Options** dialog box, the time range settings of to be applied are organised and displayed as follows:

- Select **Time Range** (left pane) to display the settings that are applied in the Alarms mode (right pane).

For example, add 5 minutes of data **before** and **after** an alarm.

---

When using the alarms historical data mode of the VibroSight Vision Time Range tool window, select **Add data before and after the alarm** and use the **before** and **after** controls to add fixed periods of



time before and/or after the time ranges defined by the severity states (alarms). This allows the measurement data stored in the VibroSight Server database to be accessed, retrieved and displayed in terms of time ranges defined by the alarms with additional time immediately before and/or after an alarm.

Previously, when working with the Time Range tool window in Alarms mode, it was necessary to convert an alarm of interest to Custom Historical mode, then manually edit the time period defined by the alarm to include additional time before/after the alarm.

### 3. Solved problems and bug fixes

#### General

#### 3.1. Improvements and bug fixes

General stability improvements and multiple bug fixes across the various VibroSight 2.11.5 software modules.

#### 3.2. Problems with VibroSight OPC

Several problems configuring and working with VibroSight OPC Servers have been resolved.

See also 2.1 VibroSight OPC Server improvements

#### 3.3. Problems with data quality indicators

The data quality information for DC Extractions (Dynamic Processing Block) and Shaft Centerline Data Entities (Dual Shaft Relative Processing Block) is incorrectly indicated as bad when the speed is zero. This incorrect quality information is displayed in VibroSight Vision plots and exported via VibroSight OPC Servers.



#### VibroSight Configurator

#### 3.4. VM600 XMx16 card qualifiers

The qualifiers (rectifiers) available for Time Domain Extractions (Dynamic Processing Blocks) have been changed as follows:

- "Scaled True Peak" has replaced "True Peak".

When "Scaled True Peak" is selected for a configuration, "Peak" is actually sent to the XMx16 card and "Scaled True Peak" is used as the default qualifier for the measurement (for example, in VibroSight Vision).

- "True Peak-Peak" has replaced "Scaled True Peak-Peak".

When "True Peak-Peak" is selected for a configuration, "Peak" is actually sent to the XMx16 card and "True Peak-Peak" is used as the default qualifier for the measurement (for example, in VibroSight Vision).

These changes better reflect what happens on an XMx16 card and in the VibroSight software, as previously:

- When an XMx16 card's time domain extraction was configured as "True Peak" (now "Scaled True Peak"), the card performs a "True Peak-Peak" divided by two. (That is, the card provides a "Scaled True Peak" and VibroSight used "True Peak" for the measurement.)

- When an XMx16 card's time domain extraction was configured in "Scaled True Peak-Peak" (now "True Peak-Peak"), the card performs a "True Peak-Peak" divided by two which VibroSight then multiplies by two. (That is, the card provides a "Scaled True Peak", VibroSight multiplied it by two and presented it as "Scaled True Peak-Peak", but it is actually a "True Peak-Peak".)

## VibroSight Event Viewer

Several problems have been resolved. For example:

- Not all System generated events (such as a card paired event) are being displayed as expected.

## VibroSight Mimic

Several problems have been resolved. For example:

- The name (**Caption**) displayed by a Value indicator object can revert from the Machinery view name ("Point") to the Hardware view name ("Processing block") when a Dimension selector object is used view different outputs (such as amplitude, phase or frequency).
- The phase output displayed by a Value indicator object when a Dimension selector object is used to select it uses a range of  $\pm 180^\circ$  (it should be 0-360°, as per the Unit Preferences).
- The **value** displayed by Value indicator objects can disappear after saving or opening a Mimic project, so that only the bar graph is displayed (the default Mode of operation for a Value indicator object is **Mini bar graph + value**).

## VibroSight System Manager

Several problems have been resolved.

## VibroSight Vision

Several problems have been resolved.

## 4. Known issues

### 4.1. Changing a VibroSight Server's maximum RAM cache size when DSNs are not used

Since VibroSight 2.9.7, a VibroSight Server database no longer requires a data source name (DSN), so it is no longer required to use the ODBC Data Source Administrator to manage the underlying connection to the Sybase SQL Anywhere 11 database (which provided convenient access to the start line command that is used to start the SQL Anywhere 11 server).

---

**NOTE:** `dbeng11.exe -ch 600m` is the default command used to start the SQL Anywhere 11 server, where the `-ch 600m` option specifies that a maximum RAM cache size of 600 MB should be used. (This option limits the underlying SQL Anywhere's database server cache during automatic cache growth.)

However, for more complex machinery monitoring applications and larger databases, it is recommended that a maximum RAM cache size of 2000 MB (`-ch 2000m`) is used, in order to improve the overall performance of the VibroSight machinery monitoring system.

---

When a DSN is not used with a VibroSight Server database, the settings usually written to the DSN using the ODBC Data Source Administrator are managed by the VibroSight Server itself and stored in the VibroSight Server configuration file (`*.vssrvcfg`). However, this means that the specification of the maximum cache size to be used by the VibroSight Server database is not as convenient to access by the user.

Presently, the default command used to start the SQL Anywhere 11 server will be used unless:

- In VibroSight Configurator, when saving the configuration as a server / database, the Configure advanced settings option is used to enter a different SQL database start line command.
- In VibroSight System Manager, when copying the database, the Configure advanced settings option is used to enter a different SQL database start line command.

So when DSNs are not used with a VibroSight Server database, the VibroSight Server configuration file (`*.vssrvcfg`) must be edited manually if it is necessary to change the SQL database start line command after a VibroSight Server database has been created or copied:

1. Exit all VibroSight software modules (clients and servers) that use the VibroSight Server database to be modified.
2. Use a text editor program to open the VibroSight Server configuration file (`*.vssrvcfg`) and search for the text string `dbeng11.exe`.
3. Edit the `StartLine="dbeng11.exe -ch 600m"` command in the configuration file to use the new required maximum cache size.  
For example, `StartLine="dbeng11.exe -ch 2000m"`, then save the file.
4. Restart the VibroSight Server.

If the `StartLine="dbeng11.exe -ch 600m"` command cannot be found in the VibroSight Server configuration file being used, then a "dummy" copy of the VibroSight Server database should be

created using VibroSight System Manager's Database Copy command with the Configure advanced settings option selected. A "dummy" VibroSight Server configuration file created in this way will include the SQL database start line command and can be used as an example to edit the VibroSight Server configuration file being used. (After which, the "dummy" files should be deleted.)

---

**NOTE:** It is highly recommended to make a backup copy of the VibroSight Server configuration file being used before manually editing it.

Such manual edits must be done carefully in order to ensure that the tags and delimiters used in the VibroSight Server configuration file are used correctly.

---

## 4.2. Display of timestamps in VibroSight Vision

In VibroSight Vision, when the timestamps (date and time) are configured to be displayed as Site time or Local computer time and the site time or local computer time is subsequently changed on the relevant computer (for example, using Windows > Control Panel > Date and Time), this change is not reflected in the VibroSight Vision user interface until the user clicks on the **Timestamp** displayed in the VibroSight Vision status bar.

## 4.3. Small "holes" in plotted data for larger VibroSight Vision projects when viewing live data

Depending on the complexity of a VibroSight application and the performance of the computer running the VibroSight software, the responsiveness of VibroSight Vision can decline under certain situations and affect the display of plots when viewing live data.

In particular, this performance issue has been seen with larger VibroSight Vision projects containing many open plots using live data. It is typically characterised by plots being displayed with small "holes" in the data, corresponding to when the computer has reached its performance limits.

If this behaviour is seen, the recommended workaround is to:

- Reduce the number of active plots in the VibroSight Vision project in order to reduce the computational load, as only the currently displayed (foreground) plots are constantly refreshed. Plots that are hidden or minimized (background) are not active and will only be refreshed when they become visible again.
- If it is necessary to view historical data at the same time, consider using a separate VibroSight Vision session to work with the historical data, preferably on a different computer.

## 4.4. Missing data for XMV16 and XMVS16 cards

When the order-tracked sampling mode is being used, XMV16 and XMVS16 cards have been seen to disappear (drop out) and produce no data for periods of 10, 20 or 30 seconds. After which, the card usually reappears without any intervention and normal operation resumes.

This issue is being investigated and appears to be a XMV16 and XMVS16 card firmware problem that is related to transitions in the input speed signal from "zero speed" to "non-zero speeds".

---

#### 4.5. VibroSight Server and Host Service restart required after changes to network adapter

If the configuration of a network adapter is changed (for example, enabled or disabled, connected or disconnected) on a computer running VibroSight, then the VibroSight Servers and Host Services running on the computer must be restarted in order for the network adapter to be recognized by the VibroSight discovery mechanism.

#### 4.6. Length limitation of VibroSight Server instance names

Since VibroSight 2.9.6, VibroSight Server instance names are limited to 18 characters, whereas up to 27 characters were allowed in previous versions. This constraint is enforced during the creation of new server instances with VibroSight 2.9.6 or later.

However, existing server instances may be non-compliant (too long) and no longer run after an upgrade of the VibroSight software. In such cases, the server instance name should be manually edited in the VibroSight configuration file (`*.vssrvcfg` or `*.config`) to be 18 characters or less. Changes may also be required in any VibroSight software that references the server instance name, for example, associated VibroSight Vision Projects.

For automated database copies that append a timestamp (`_yyyyMMddHHmmss`) to the Server instance name, the number that remain available for VibroSight Server instance names is deduced to 3 characters. Alternatively, the server instance name can be shorted after the database copy is complete.

#### 4.7. VibroSight client connections to local and remote VibroSight Servers are mutually exclusive

When a VibroSight Server is running on a (local) computer, a VibroSight client, such as VibroSight Configurator or VibroSight Vision running on the same (local) computer cannot connect to a VibroSight Server running on a different (remote) computer.

#### 4.8. VibroSight Servers listen to a single IP address

VibroSight Servers use one specific IP address for connections to VibroSight clients. This IP address can be set to any of the available LAN adapters or logical addresses on the host computer, such that all traffic is directed through this address. However, this prevents concurrent connections from VibroSight clients running on other computers through different IP addresses.

#### 4.9. Gaps in logged Modbus data

When data logging with pre-trigger is used (for example, a time-based data logging rule with Pre Logging selected) or database operations such as a database copy or a database purge command occur at the same time as standard data logging, gaps can appear in the Modbus data that has been logged at a standard rate.

These gaps in Modbus data are related to the computation of alarms when data is written to the database, which can be slow and can prevent some subsequent Modbus data from being handled correctly, especially when VibroSight Server is busy with other data intensive tasks.

#### **4.10. Display of timestamps in VibroSight clients other than VibroSight Vision**

Although VibroSight Vision now supports the display of timestamps (date and time) as either Site time, UTC time or Local computer time, all other VibroSight client software modules continue to display timestamps in local computer time only (that is, the date and time according to the local clock of the computer running the VibroSight software module).

#### **4.11. Display of devices in VibroSight System Manager**

In the System Explorer window of VibroSight System Manager, the Devices tree-view does not always update correctly to show all of the devices (VM600 cards and VibroSmart DMS devices) available on the network.

In particular, this has been seen when changing the firmware of a device, and can persist even after a refresh (using the **Refresh** toolbar button or **View > Refresh**).

If this behaviour is seen, the recommended workaround is to:

- Wait a few minutes and refresh again.
- Restart VibroSight System Manager.

#### **4.12. VibroSight Mimic backwards compatibility**



VibroSight 2.10.0 contained significant improvements and changes, including a separate VibroSight Mimic client software module for mimics (that were previously available in VibroSight Vision). As a result, VibroSight Vision mimics created with VibroSight 2.9.7 or earlier are not compatible with VibroSight 2.10.0 or later.

VibroSight 2.11.0 contained significant improvements and changes to the VibroSight Mimic client software module. As a result, VibroSight Vision mimics created with VibroSight 2.10.1 or earlier are not compatible with VibroSight 2.11.0 or later.

## 5. Compatibility

---

**NOTE:**

Refer also to the latest version of the  *Getting started with VibroSight* installation guide or the  *VibroSight software* data sheet for further information on VibroSight's prerequisites and compatibility.



---

As part of the VibroSight software installation process, the installation wizard will automatically check to see if the "Microsoft Visual C++ Redistributable Package" (see section 5.1.6) and the "OPC Core Components Redistributable (x86)" (see section 5.1.7) are available on the computer.

If these items have not previously been installed and they are required by the VibroSight installation's application, then the VibroSight installation wizard can be used to install them.

### 5.1. VibroSight software

VibroSight 2.11.5 is an update version release in the 2.x.x series and replaces VibroSight 2.11.4.

Compatibility with existing databases is achieved using the database  **Update** tool (from VibroSight System Manager's  **Database** tools) which supports the continued used of configurations and data from previous versions. See 6.2.1 Updating the internal structure of a VibroSight database.

#### 5.1.1. Microsoft Windows operating systems

VibroSight 2.11.5 is compatible with 32-bit versions and 64-bit versions of Microsoft® Windows® operating systems.

---

**NOTE:**

Since VibroSight 2.9.0, VibroSight can run on 64-bit versions of Windows in order to help eliminate memory and performance issues that can occur due to the limitations of the 32-bit memory space.

However, VibroSight 2.11.x remains 32-bit software that runs on x64 Windows in the same manner as it does on 32-bit windows, that is, VibroSight is "x64-compatible" software (not "native x64" software).

---

See the appendix of this document for detailed information on VibroSight software and Windows operating system compatibility.



## 5.1.2. Microsoft .NET Framework

For most Windows operating systems, VibroSight 2.11.5 requires that the Microsoft .NET Framework 4.5 is installed on the computer.

---

**NOTE:** Microsoft .NET Framework 4.5 is required since VibroSight 2.9.4. Microsoft .NET Framework 4 (Standalone Installer) is required for VibroSight 2.9.2 and 2.9.3. Microsoft .NET Framework 3.5 SP1 is required for VibroSight 2.9.1 or earlier.

---

See the appendix of this document for detailed information on VibroSight software's Microsoft .NET Framework requirements.

## 5.1.3. Sybase SQL Anywhere 11 software

VibroSight uses the Sybase® SQL Anywhere 11 database software in its standard configuration. VibroSight 2.11.5 remains compatible with the previously deployed version of SQL Anywhere, namely SQL Anywhere version 11.0.1.2044.

---

**NOTE:** VibroSight requires the 32-bit version of SQL Anywhere 11 on both 32-bit and 64-bit Windows operating systems. It is strongly recommended that only the 32-bit version of SQL Anywhere 11 is installed on the computer running VibroSight.

**NOTE:** Updating SQL Anywhere to version 11.0.1.2867 is **mandatory** in order to avoid potential memory issues (fixed by Sybase). A software update (patch) included on the Sybase CD must be run in order to update Sybase SQL Anywhere from version 11.0.1 to version 11.0.1.2867: *SA11\_Full\_Win32+x64.1101\_2867\_EBF.exe*. See 6.3 Upgrading the Sybase SQL Anywhere 11 software.

---

## 5.1.4. VM600 CMS software

The VM600 CMS software from Meggitt Sensing Systems uses Sybase SQL Anywhere 8. Both Sybase SQL Anywhere 8 (VM600 CMS) and Sybase SQL Anywhere 11 (VibroSight) can be installed on the same computer.

However, while SQL Anywhere 8 and SQL Anywhere 11 can be installed on the same computer and run at the same time for standard database operations, certain administrative tasks are mutually exclusive and may block one another.

More specifically, all operations that refer to Sybase ISQL (a command-line Interactive SQL utility) in the background could be directed to the wrong version of Sybase SQL Anywhere. For example, this impacts all user operations and system operations involving the creation, copying and updating of databases.

---

**NOTE:** It is recommended to install and use VibroSight on a computer that does not have the VM600 CMS software installed.

---

---

### 5.1.5. SIMATIC Step 7 software

The SIMATIC Step 7 software from Siemens typically uses Sybase SQL Anywhere 9. Both Sybase SQL Anywhere 9 (SIMATIC Step 7) and Sybase SQL Anywhere 11 (VibroSight) can be installed on the same computer.

However, while SQL Anywhere 9 and SQL Anywhere 11 can be installed on the same computer, they cannot run at the same time.

More specifically, if SIMATIC Step 7 and VibroSight are both installed, certain administrative tasks, such as all user operations and system operations involving the creation, copying and updating of databases, may not work correctly. If this behaviour is seen, the recommended workaround is to manually change or remove the SQLANY environmental variable in order to allow VibroSight to work correctly.

Note: The SQLANY environment variable is used to contain the directory where Sybase SQL Anywhere is installed.

---

**NOTE:** It is recommended to install and use VibroSight on a computer that does not have the SIMATIC Step 7 software installed.

---

### 5.1.6. Microsoft Visual C++ Redistributable Package

The Microsoft Visual C++ Redistributable Package is required in order to install and register the Visual C++ libraries required by a VibroSight OPC server.

If this package does not already exist on the computer, then the VibroSight installation wizard will install it automatically. (The package is included in the ISSetupPrerequisites folder on the VibroSight CD.)

---

**NOTE:** The Microsoft Visual C++ Redistributable Package is required since VibroSight 2.9.4, if VibroSight OPC servers are being used.

The 32-bit version of the package (“vcredist\_x86.exe”) is installed on both 32-bit and 64-bit Windows operating systems, as the VibroSight OPC server is a 32-bit application.

---

### 5.1.7. OPC Foundation OPC Core Components Redistributable

The OPC Core Components Redistributable is required in order to configure and run VibroSight OPC clients and OPC servers correctly: the redistributable must be installed on OPC client computers in order to allow connections to remote OPC servers and it must be installed on OPC server computers in order to allow OPC clients to browse for running OPC servers.

If this redistributable does not already exist on the computer, then the VibroSight installation wizard will install it automatically. (The redistributable is included in the ISSetupPrerequisites folder on the VibroSight CD.)

---

**NOTE:** The OPC Core Components Redistributable is required since VibroSight 2.9.4, if OPC clients or OPC servers are being used.

The 32-bit version of the package (“OPC Core Components Redistributable (x86)”) is installed on 32-bit Windows operating systems and the 64-bit version of the package (“OPC Core Components Redistributable (x64)”) is installed on 64-bit Windows operating systems.

---

## 5.2. VM600 cards

### 5.2.1. Firmware

There are no firmware updates for VM600 cards corresponding to VibroSight 2.11.5.

The latest firmware for the CPUR remains:

- Applications: applications-640-012-001-003.tgz
- Base System: base-system-640-011-001-003.tgz.

The latest firmware for the XMC16, XMV16 and XMVS16 remains:

- Applications: applications-640-010-001-009.tgz
- Base System: base-system-640-003-001-010.tgz.

Therefore, for current versions of the VibroSight-compatible VM600 cards, no firmware upgrades are required.

## 5.3. VibroSmart DMS devices

### 5.3.1. Firmware

There are no firmware updates for the VibroSmart DMS modules and devices corresponding to VibroSight 2.11.5.

The latest firmware for the VSI010 module remains:

- 642-002-001-005.xmsifw.

The latest firmware for the VSN010 device remains:

- 642-004-001-007.redboxfw.

The latest firmware for the VSV300 module remains:

- 642-001-001-009.xtranfw.

Therefore, for current versions of the VibroSmart DMS modules and devices, no firmware upgrades are required.

---

**NOTE:** VibroSight 2.11.1 and earlier are not compatible with the latest versions of VibroSmart DMS module firmware.

---

## 6. Upgrade procedure

This section describes the procedure for upgrading a VibroSight system from a previous version. Perform the steps in the given sequence in order to complete a system upgrade.

---

**NOTE:** It is strongly recommended to verify the version of firmware running in the related hardware (XMx16 cards and VibroSmart DMS modules and devices) before starting a VibroSight system upgrade, in order to establish if any firmware updates are also required.  
See 6.4.3 Updating the firmware using VibroSight System Manager.

---

---

**NOTE:** It is strongly recommended to ensure that a copy of the configuration for a VibroSmart DMS is available before updating the firmware of any of the VibroSmart DMS modules used in the DMS. See 6.4.3 Updating the firmware using VibroSight System Manager.

---

### 6.1. VibroSight software user settings

The VibroSight Software generates and uses some files on the hard disk of the computer running VibroSight to keep track of user-configurable settings, so that these settings are remembered and applied for the VibroSight installation.

These settings files have an `.xmssettings` file name extension and on a computer running Windows 7, can be found here:

C:\Users\*username*\AppData\Roaming\Meggitt\VibroSight 2, where *username* is the Windows account name.

For example, the `VibroSightVision.xmssettings` file records the user-configurable default settings for VibroSight Vision, such as default settings for plots.

---

**NOTE:** VibroSight software updates and upgrades do not replace these settings files, so:

- For a computer on which VibroSight was previously installed, an update, upgrade or a re-installation of VibroSight will continue to use the previous defaults recorded in the `.xmssettings` files.
- For a computer on which VibroSight was not previously installed, the installation of VibroSight will generate and use new `.xmssettings` files, which use the latest VibroSight software defaults.

If a settings file is deleted for any reason, VibroSight will generate and use a new settings file, which uses the latest VibroSight software defaults.

---

## 6.2. Upgrading the VibroSight software

---

**NOTE:** Since VibroSight 2.9.6, VibroSight Server instance names are limited to 18 characters (previously, it was 27). So VibroSight installations with VibroSight Server instance names of more than 18 characters will experience problems with VibroSight 2.11.x until the existing VibroSight Server instance names (and any references to them) are manually edited to be 18 characters or less. See 4.6 Length limitation of VibroSight Server instance names.

---



1. If it is not necessary for the VibroSight-based system to remain operational during the upgrade procedure, back up any important (required) VibroSight databases in the following way:
  - Exit all VibroSight software modules (clients and servers) – no VibroSight software modules, such as Vision, Configurator or Server, should be running.
  - Copy the files (\*.vssrvdb, \*.vssrvcfg and optionally, \*.log) from the directory where your database files are located to another location, for example, to a specific backup directory.

---

**NOTE:** The default data (data path) directory is C:\VibroSight Data




---

Or if it is necessary for the VibroSight-based system to remain operational for as long as possible during the upgrade procedure, back up any important (required) VibroSight databases in the following way:

- Exit all VibroSight software modules (clients) – no VibroSight software modules, such as Vision or Configurator, should be running.
- Start VibroSight System Manager and use the database  **Backup** tool from VibroSight System Manager's  **Database** tools, and follow the instructions presented by the Database Backup Wizard.

---

**NOTE:** It is necessary to be logged in to System Manager as 'Admin' in order to have the user rights to access the database tools:

Select your  VibroSight Host (computer) in the System Explorer tree structure and click  **Login** (from VibroSight System Manager's  **Access Rights** tools).

Refer also to the *Backing up a database* topic in the  *VibroSight help*.

---

2. Make backup copies of any important (required) VibroSight Vision projects in the following way:


- Create an archive file (for example, \*.zip) containing all of the files (\*.xml and \*.xmsproj) in the directory where your project files are located.

---

**NOTE:** The default project directory is:  
C:\Documents and settings\username\My Documents  
\VibroSight\Projects

---


3. Ensure that no VibroSight software modules are running.

4. Remove the currently installed version of the VibroSight software (for example,  VibroSight Standard Edition) using Windows Add or Remove Programs, in one of the following ways:

- Click **Start > Settings > Control Panel** and then double-click **Add or Remove Programs**.
- Or click **Start**, click **Control Panel** and then double-click **Add or Remove Programs**.

5. Install the latest version of the VibroSight software by inserting the VibroSight CD into the CD/DVD drive of the computer and follow the instructions presented by the VibroSight installation wizard.

---

**NOTE:** Refer to the  *Getting started with VibroSight* installation guide for detailed information on installing the VibroSight software – including prerequisites and compatibility.

---

6. Restart VibroSight Server and ensure that the required communications are enabled. For example, enable card and module device drivers according to the hardware in the system:

- For example, click **Data > Acquisition > XMC16/XMV16 Card Driver** or **Data > Acquisition > VibroSmart Module Driver**.



7. Restart VibroSight Vision and ensure that live data is being received from the hardware and displayed in Vision.

8. The VibroSight system is now up and running.

### 6.2.1. Updating the internal structure of a VibroSight database




When VibroSight Server is started, it checks the status of the database and will automatically inform the user if any internal structures of the database need to be updated before proceeding.

1. Update a VibroSight database in the following way:

- Start VibroSight System Manager and use the database  **Update** tool from VibroSight System Manager's  **Database** tools, and follow the instructions presented by the Database Update Wizard.

---

**NOTE:** It is necessary to be logged in to System Manager as 'Admin' in order to have the user rights to access the database tools:

Select your  VibroSight Host (computer) in the System Explorer tree structure and click  **Login** (from VibroSight System Manager's  **Access Rights** tools).

Refer also to the *Updating a database* topic in the  *VibroSight help*.

---

### 6.3. Upgrading the Sybase SQL Anywhere 11 software

VibroSight software is compatible (and extensively tested) with Sybase SQL Anywhere versions 11.0.0 and 11.0.1.

However, with the release of SQL Anywhere version 11.0.1.2867, Sybase has fixed some previously known memory issues. Therefore, it is **mandatory** to upgrade all VibroSight systems to this version of SQL Anywhere 11.

Determine the version of the SQL Anywhere 11 database engine installed on a computer in the following way:


1. From the Start menu, click **Start > All Programs > SQL Anywhere 11 > Sybase Central**.

The Sybase Central window appears. Sybase Central is a GUI-based management tool for Sybase products.

2. Click **Help > About Sybase Central**.

The About Sybase Central windows appears, displaying the version information for SQL Anywhere 11 (and any other installed Sybase products).

---

**NOTE:** Refer also to the *Determining the version of SQL Anywhere 11 installed on a computer* topic in the  *VibroSight help*.

---

If SQL Anywhere 11 version 11.0.0 is installed on the computer, it is necessary to first remove version 11.0.0, then install version 11.0.1 from the Sybase CD.

If SQL Anywhere 11 version 11.0.1 is installed on the computer, simply update to version 11.0.1.2867 by running the software update (patch) included on the Sybase CD.




When SQL Anywhere 11 software version 11.0.0 is installed on the computer:

---


**NOTE:** Do not use the SQL Anywhere 11.0.1 setup to upgrade directly to software version 11.0.1 from software version 11.0.0. Instead, it is necessary to upgrade the Sybase database software as follows:

1. Remove SQL Anywhere 11.0.0, using the Windows Add or Remove Programs tool.
2. Install SQL Anywhere 11.0.1, using the Sybase SQL Anywhere 11.0.1 CD.

Refer also to the  *Getting started with VibroSight* installation guide for information on installing the Sybase software.

---

1. Exit all VibroSight software modules (clients and servers) – no VibroSight software modules, such as Vision, Configurator or Server, should be running – as this also stops the SQL Anywhere 11 database engine.

The  lightning icon that appears in the notification area (at the far right of the task bar) to indicate that a Sybase database engine is running should no longer be shown.

2. Remove the currently installed version of Sybase SQL Anywhere 11 using Windows Add or Remove Programs, in one of the following ways:

- Click **Start > Settings > Control Panel**, then double-click **Add or Remove Programs**
- Or click **Start**, click **Control Panel** and then double-click **Add or Remove Programs**.

And remove  SQL Anywhere 11.

3. Restart the computer.
4. Install Sybase SQL Anywhere VibroSight 11.0.1.2044 by inserting the Sybase CD into the CD/DVD drive of the computer and following the instructions presented by the SQL Anywhere 11 installation wizard.
5. Restart the computer.

Without this final computer restart, VibroSight Server may not be able to start the SQL Anywhere 11 database engine.

When SQL Anywhere 11 software version 11.0.1 is installed on the computer:

1. Update to Sybase SQL Anywhere VibroSight 11.0.1.2867 by inserting the Sybase CD into the CD/DVD drive of the computer, running the *SA11\_Full\_Win32+x64.1101\_2867\_EBF.exe* software update (patch) and following the instructions presented by the SQL Anywhere 11 installation wizard.
2. Restart the computer.

## 6.4. Updating the VibroSight hardware

Appropriate files and tools are included in the installation package to allow VM600 cards (CPUR and XMx16) and VibroSmart DMS devices (VSI010, VSN010 and VSV300) to be updated to the latest firmware, in order to take advantage of improvements to the VibroSight software.

Updating the firmware VM600 cards or VibroSmart DMS devices is a special task that can, if used unintentionally or incorrectly, lead to malfunctioning of the device and affect proper function of data acquisition.

During the firmware update of a device, the card or module being updated cannot provide its normal machinery monitoring functions because its outputs (alarms and relays) can go to undetermined states, irrespective of how they have been configured.

For VibroSmart DMS modules, the machinery being monitored is not protected for the duration of a firmware update and the restart (reboot) that is triggered automatically after the firmware update (which can take up to 5 minutes).

---

**NOTE:** It is highly recommended that firmware updates are only performed in accordance with the operating procedures for the machinery being monitored and that appropriate precautions are taken at the control system level (such as DCS or PLC).

For example, alarms and relay outputs should be ignored (bypassed or inhibited) in order to avoid false trips of the machinery being monitored.

---

### 6.4.1. VM600 card firmware

The latest VM600 card firmware files are copied to a directory on your computer as part of the VibroSight software installation process.

---

**NOTE:** For example, the default firmware directory for VM600 cards is:

```
C:\Program Files\Meggitt\VibroSight 2\Firmware\VM600
```

---

The firmware files for a VM600 card can be found in the appropriate subfolder and identified by their .tgz file name extension. For example, the `XMV16` subfolder contains the applications and base system firmware for use by XMV16 cards. Any additional firmware updates received from Meggitt Sensing Systems should also be stored in these directories.

Table 1 shows the compatibility between VibroSight software and VM600 XMx16 card hardware (that is, XMC16, XMV16 and XMVS16 card pair firmware).

---

**NOTE:** It is strongly recommended to use the most recent version of the VM600 XMx16 card firmware that is compatible with the version of VibroSight software being used.

---

Table 1: VibroSight software and VM600 XMx16 card firmware compatibility

		VM600 XMx16 firmware					
		Base-system (*.tgz)					
VibroSight software version	CD part number	640-003-001-005	640-003-001-006	640-003-001-007	640-003-001-008	640-003-001-009	640-003-001-010
		Applications (*.tgz)					
		640-010-001-004	640-010-001-005	640-010-001-006	640-010-001-007	640-010-001-008	640-010-001-009
<b>2.9.3</b>	609-004-000-013	✓ See note 1	✓ See note 1	✓ See note 1			
<b>2.9.4</b>	609-004-000-014	✓	✓	✓			
<b>2.9.5</b>	609-004-000-015	✓	✓	✓			
<b>2.9.6</b>	609-004-000-016	✓	✓	✓			
<b>2.9.7</b>	609-004-000-017				✓ See note 2		
<b>2.10.0</b>	609-004-000-018				✓ See note 2		
<b>2.10.1</b>	609-004-000-019				✓ See note 2		
<b>2.11.0</b>	609-004-000-020				✓ See note 2	✓ See notes 2 and 3	
<b>2.11.1</b>	609-004-000-021						✓ See note 4
<b>2.11.2</b>	609-004-000-022						✓
<b>2.11.3</b>	609-004-000-023						✓
<b>2.11.4</b>	609-004-000-024						✓
<b>2.11.5</b>	609-004-000-025						✓

Notes for Table 1 (see the next page)

---

**Notes for Table 1**

1. VibroSight 2.9.1 or later is not compatible with any previous versions of the VM600 card firmware as the protocol between the SW and the FW has changed (to improve the implementation of the card type handling between the SW and the cards, required for the XMVS16 card).
2. Updating to these versions of VM600 XMx16 card firmware requires a two-step process:
  - (i) VibroSight System Manager's Change Firmware command should be used to update the base-system firmware (640-003-001-00\*.tgz) only.
  - (ii) Then the Change Firmware command should be used again to update the applications firmware (640-010-001-00\*.tgz) only.
3. This version of VM600 XMx16 card firmware introduces support for the direct measurement mode that is used to acquire direct data (digitised waveform) before an event.
4. This version of VM600 XMx16 card firmware introduces support for the operation of a VibroSight system without an NTP server (NTP-free).

## 6.4.2. VibroSmart DMS device firmware

The latest VibroSmart DMS device firmware files are copied to a directory on your computer as part of the VibroSight software installation process.

---

**NOTE:** The default firmware directory for VibroSmart DMS devices is:  
`C:\Program Files\Meggitt\VibroSight 2\Firmware\VibroSmart`

---

The firmware files for a VibroSmart DMS device can be found in the appropriate subfolder and identified by their \*.fw file name extension. For example, the `VSV300` subfolder contains the firmware for use by VSV300 modules. Any additional firmware updates received from Meggitt Sensing Systems should also be stored in these directories.

Table 2 shows the compatibility between VibroSight software and the VibroSmart VSI010 module firmware.

Table 3 shows the compatibility between VibroSight software and the VibroSmart VSN010 device firmware.

Table 4 shows the compatibility between VibroSight software and the VibroSmart VSV300 module firmware.

---

**NOTE:** It is strongly recommended to use the most recent version of the VibroSmart DMS firmware that is compatible with the version of VibroSight software being used.

---

Table 2: VibroSight software and VibroSmart VSI010 module firmware compatibility

VibroSight software version CD part number	VibroSmart VSI010 firmware		
	642-002-001-002.xmsifw	642-002-001-004.xmsifw	642-002-001-005.xmsifw
<b>2.9.6</b> 609-004-000-016	✓		
<b>2.9.7</b> 609-004-000-017	✓		
<b>2.10.0</b> 609-004-000-018	✓		
<b>2.10.1</b> 609-004-000-019	See note 1		
<b>2.11.0</b> 609-004-000-020			
<b>2.11.1</b> 609-004-000-021			
<b>2.11.2</b> 609-004-000-022		✓ See note 2	
<b>2.11.3</b> 609-004-000-023		✓ See note 2	
<b>2.11.4</b> 609-004-000-024			✓
<b>2.11.5</b> 609-004-000-025			✓

**Notes for Table 2**

1. VibroSight 2.10.1, 2.11.0 and 2.11.1 included features that were activated in order to ensure compatibility with development versions of VibroSmart DMS device firmware. However, only the later versions of each should now be used, for example, VibroSight 2.11.4 and the VSI010 642-002-001-005 firmware.

2. Updating to these versions of VibroSmart VSI010 firmware requires a two-step process:

- (i) All VSI010 devices in the DMS should be upgraded to the latest .xmsifw firmware and all VSV300 devices in the DMS should be upgraded to the latest .xtranfw firmware.

Note: It is necessary to wait until these VibroSmart DMS modules have automatically restarted after the firmware update before continuing, that is, for up to 10 minutes (up to 5 minutes for the firmware update and up to 5 minutes for the duration of the restart (reboot)).

- (ii) Then all VSN010 devices in the DMS should be upgraded to the latest .redboxfw firmware.

As these versions of VibroSmart DMS device firmware enable the rapid spanning tree protocol (RSTP), this sequence is necessary in order to avoid broadcast storms on the network.

Table 3: VibroSight software and VibroSmart VSN010 device firmware compatibility

VibroSight software version CD part number	VibroSmart VSN010 firmware				
	642-004-001-002.redboxfw	642-004-001-003.redboxfw	642-004-001-005.redboxfw	642-004-001-006.redboxfw	642-004-001-007.redboxfw
<b>2.9.6</b> 609-004-000-016	✓				
<b>2.9.7</b> 609-004-000-017	✓	✓			
<b>2.10.0</b> 609-004-000-018		✓			
<b>2.10.1</b> 609-004-000-019	See note 1				
<b>2.11.0</b> 609-004-000-020					
<b>2.11.1</b> 609-004-000-021					
<b>2.11.2</b> 609-004-000-022				✓ See note 2	
<b>2.11.3</b> 609-004-000-023				✓ See note 2	
<b>2.11.4</b> 609-004-000-024					✓
<b>2.11.5</b> 609-004-000-025					✓

**Notes for Table 3**

1. VibroSight 2.10.1, 2.11.0 and 2.11.1 included features that were activated in order to ensure compatibility with development versions of VibroSmart DMS device firmware. However, only the later versions of each should now be used, that is, VibroSight 2.11.4 and the VSN010 642-004-001-007 firmware.

2. Updating to these versions of VibroSmart VSN010 firmware requires a two-step process:

(i) All VSI010 devices in the DMS should be upgraded to the latest .xmsifw firmware and all VSV300 devices in the DMS should be upgraded to the latest .xtranfw firmware.

Note: It is necessary to wait until these VibroSmart DMS modules have automatically restarted after the firmware update before continuing, that is, for up to 10 minutes (up to 5 minutes for the firmware update and up to 5 minutes for the duration of the restart (reboot)).

(ii) Then all VSN010 devices in the DMS should be upgraded to the latest .redboxfw firmware.

As these versions of VibroSmart DMS device firmware enable the rapid spanning tree protocol (RSTP), this sequence is necessary in order to avoid broadcast storms on the network.

Table 4: VibroSight software and VibroSmart VSV300 module firmware compatibility

VibroSight software version CD part number	VibroSmart VSV300 firmware					
	642-001-001-003.xtranfw	642-001-001-004.xtranfw	642-001-001-006.xtranfw	642-001-001-007.xtranfw	642-001-001-008.xtranfw	642-001-001-009.xtranfw
<b>2.9.6</b> 609-004-000-016	✓					
<b>2.9.7</b> 609-004-000-017	✓	✓				
<b>2.10.0</b> 609-004-000-018		✓				
<b>2.10.1</b> 609-004-000-019	See note 1					
<b>2.11.0</b> 609-004-000-020						
<b>2.11.1</b> 609-004-000-021						
<b>2.11.2</b> 609-004-000-022				✓ See note 2	✓ See note 2	
<b>2.11.3</b> 609-004-000-023					✓ See note 2	
<b>2.11.4</b> 609-004-000-024						✓
<b>2.11.5</b> 609-004-000-025						✓

**Notes for Table 4**

1. VibroSight 2.10.1, 2.11.0 and 2.11.1 included features that were activated in order to ensure compatibility with development versions of VibroSmart DMS device firmware. However, only the later versions of each should now be used, that is, VibroSight 2.11.2 and the VSV300 642-001-001-009 firmware.

2. Updating to these versions of VibroSmart VSV300 firmware requires a two-step process:

- (i) All VSI010 devices in the DMS should be upgraded to the latest .xmsifw firmware and all VSV300 devices in the DMS should be upgraded to the latest .xtranfw firmware.

Note: It is necessary to wait until these VibroSmart DMS modules have automatically restarted after the firmware update before continuing, that is, for up to 10 minutes (up to 5 minutes for the firmware update and up to 5 minutes for the duration of the restart (reboot)).

- (ii) Then all VSN010 devices in the DMS should be upgraded to the latest .redboxfw firmware.

As these versions of VibroSmart DMS device firmware enable the rapid spanning tree protocol (RSTP), this sequence is necessary in order to avoid broadcast storms on the network.



### 6.4.3. Updating the firmware using VibroSight System Manager

When performing VibroSight software upgrades, it is strongly recommended to systematically upgrade the firmware of VM600 XMx16 cards and VibroSmart DMS devices to the latest compatible version.

Failure to perform a necessary VibroSight-compatible VM600 card firmware update may lead to incoherent system behaviour and affect the proper functioning of data acquisition in a system. It is only in systems where the firmware running on the XMx16 cards and VibroSmart DMS devices already corresponds to the latest available version that no firmware update is required. Therefore, it is strongly recommended to verify the version of firmware running on the hardware before starting a VibroSight system upgrade, in order to establish if a firmware update is also required.

---

**NOTE:** Changing the firmware of the VibroSight hardware is a special administrative task that can – if performed unintentionally – affect the proper functioning of data acquisition in a system.

It is therefore strongly recommended to change the firmware of the VibroSight hardware only when it is necessary. For example, when the devices must be updated to be compatible with a VibroSight software upgrade.

---

For VibroSmart DMS modules, each module can be selected and its firmware updated individually. Alternatively, multiple modules of the same type (for example, VSV3x0) can be updated to the same version of firmware at the same time.

---

**NOTE:** It is strongly recommended to ensure that a copy of the configuration for a VibroSmart DMS is available before updating the firmware of any of the VibroSmart DMS modules used in the DMS.


For example, using the currently installed version of VibroSight (that is, before any updates to the VibroSight software corresponding to updates to VibroSmart DMS modules), VibroSight Configurator should be used to obtain a copy of the configuration as follows:

For a VibroSmart DMS using a VibroSight Server, the **File > Open > Server / Database** command can be used to read the configuration from the VibroSight Server.

For a VibroSmart DMS not using a VibroSight Server (that is, a “stand-alone” VibroSmart DMS), the **File > Open > Device** command can be used to read the configuration directly from the VibroSmart DMS modules.

Then the **File > Save As > File** command should be used to store a copy of the configuration for the VibroSmart DMS.

---

Update the firmware on a VibroSight device using the  **Change Firmware** tool (from VibroSight System Manager’s **Maintenance** tools):

1. Ensure that the computer running the VibroSight software is on the same network as the hardware (XMx16 card or VibroSmart DMS module or device) to be updated.

2. Start VibroSight System Manager and navigate to the Devices tree structure in the System Explorer window.

The Devices tree lists all of the VibroSight compatible hardware that VibroSight can see on the network. If there are no XMx16 cards or VibroSmart DMS devices in the tree structure or some cards are missing, verify your network connections.

3. Select the card or device that requires its firmware to be changed.

The Actions tool window updates to show the available tools.

To change multiple VibroSmart DMS to use the same version of firmware at the same time, use CTRL+click or SHIFT+click to select multiple devices from the Devices tree-view. (Then, when the Change Firmware command is run, all of the devices that were selected will be updated at the same time.)

4. Click  **Change Firmware** in the Maintenance tools group of the Actions window.

The Change Firmware dialog box appears.

5. Click the **Add** button and select the new firmware files for the card or new firmware file for the device.

---

**NOTE:** The Change Firmware dialog box automatically opens the firmware folder corresponding to the VibroSight-compatible VM600 card or VibroSmart DMS device selected.

.tgz files are for VM600 cards and \*.fw files are for VibroSmart DMS devices.

---


6. Click the **Finish** button to start the firmware upgrade process.

For XMx16 cards and VibroSmart DMS devices, the firmware upgrade process can take up to 5 minutes, during which:

- The IP address beside the device's serial number in the Devices tree structure can disappear.
- The LEDs on the front panel of the device can change to reflect the status of the upgrade.

7. Repeat steps 3 to 6 for each device that requires a firmware update.


---

**NOTE:** Although the firmware for each VibroSight device must be changed individually using the  **Change Firmware** tool, as each device updates its firmware independently of the VibroSight software (once the process has started), firmware updates can be performed on several devices in parallel.


---

8. After the firmware upgrade, verify that the VibroSight system is acquiring data from the cards.

---

**NOTE:** Refer also to the *Changing the firmware* topics in the  *VibroSight* help.

---

The  **Change Firmware** tool can be used to load a VibroSight device with any version of firmware. It is therefore possible to change a device's firmware to any previously available version, as well as the latest update.

This feature can be useful in certain situations, for example, swapping spare VibroSight hardware between different VM600 racks or VibroSmart DMSs, where systems are operating with different versions of VibroSight.

## 6.5. Final checks

After upgrading the VibroSight software, the following checks are recommended to ensure that VibroSight has not been inadvertently modified and that it continues to operate as expected:

- Use VibroSight Configurator to run a consistency check on the configuration in order to ensure that the configuration has not been modified by any changes to the VibroSight software, internal database structure and firmware for the hardware (VM600 cards and VibroSmart DMS modules).
- Use the VibroSight Server window to check that the data acquisition, data post-processing and data logging settings are as expected. (Click **Data > Acquisition**, **Data > Post-processing** and **Data > Logging** and disable/enable the drivers, processing managers and logging as required.)

## 7. Customer support

### 7.1. Contacting us

Meggitt Sensing Systems worldwide customer support network offers a range of support including Technical support and Sales and repairs support. For customer support, please contact your local Meggitt Sensing Systems representative. Alternatively, contact our main office:

Customer support  
Meggitt SA  
Route de Moncor 4  
PO Box 1616  
CH-1701 Fribourg  
Switzerland

Telephone: +41 (0) 26 407 11 11  
Email: [energysupport@ch.meggitt.com](mailto:energysupport@ch.meggitt.com)  
Web: [www.meggittsensing.com](http://www.meggittsensing.com)

### 7.2. Technical support

Meggitt Sensing Systems technical support team provide both pre-sales and post-sales technical support, including:

- General advice
- Technical advice
- Troubleshooting
- Site visits.

### 7.3. Sales and repairs support

Meggitt Sensing Systems sales team provide both pre-sales and post-sales support, including advice on:

- New products
- Spare parts
- Repairs.

## Appendix

### VibroSight software and Windows operating system compatibility

	Windows XP and Windows Server 2003 R2	Windows Vista and Windows Server 2008	Windows 7 and Windows Server 2008 R2	Windows 8 and Windows Server 2012
<b>VibroSight software compatible?</b>	Yes, but not recommended for new installations as Microsoft support for Windows XP SP3 ends on 08 June 2014	Yes, but not recommended. Windows Server 2008 R8 should be used instead of Windows Server 2008	Yes – recommended for new installations	To be announced

### Microsoft .NET Framework versions pre-installed on Windows operating systems

	Windows XP and Windows Server 2003 R2	Windows Vista and Windows Server 2008	Windows 7 and Windows Server 2008 R2	Windows 8 and Windows Server 2012
<b>Microsoft .NET Framework pre-installed on Windows operating system</b>	None on XP. .NET Framework 2.0 on Server 2003 R2	.NET Framework 3.0	.NET Framework 3.0 SP1	.NET Framework 4.5

### VibroSight software's Microsoft .NET Framework requirements

VibroSight software version	Windows XP and Windows Server 2003 R2	Windows Vista and Windows Server 2008	Windows 7 and Windows Server 2008 R2	Windows 8 and Windows Server 2012
VibroSight 2.9.1 or earlier	.NET Framework 3.5 SP1	.NET Framework 3.5 SP1	.NET Framework 3.5 SP1	.NET Framework 3.5 SP1
VibroSight 2.9.2 and 2.9.3	.NET Framework 4	.NET Framework 4	.NET Framework 4	.NET Framework 4
VibroSight 2.9.4 or later	.NET Framework 4 <sup>1</sup>	.NET Framework 4.5	.NET Framework 4.5	.NET Framework 4.5